

# Vendor Managed Gas

Quick Start Guide - page 1



## You Received:

Collector Box (includes installed battery that will last up to one week with no other power source)

Power cord for Collector Box

Y Harness

Transducer

Sensor with cord attached

1 Zip-tie

2 strips of Velcro

## You Will Need:

Plumbers Tape

Adjustable Wrench

## Important Info before you get started:

VMG can be used with any non-flammable gas.

VMG can be used with any size high pressure cylinder.

Collector must be within 300ft of sensor that sits on the cylinder.

## Set-up instructions | assembly time: 3 min

Take the collector box and attach the power cord by screwing the threaded connector to the back of the collector box. Plug the collector box into a 110/120 AC outlet.

Remove the gauge on a high side and install the Y connector that was provided in the package. Replace the high side gauge at one end of the Y connection. At the other end, install the transducer.

Attach the cord from the sensor to the transducer and listen for it to click into place.

Affix the sensor to the cylinder using either the zip-tie or the Velcro strips provided.

As you begin to use the cylinder, your readings will begin to register within a 24hr period.

# Vendor Managed Gas

Quick Start Guide - page 2



## Just FYI:

The sensor transmits data from the cylinder to the collector box in one tenth of a second via RF transmission.

The 9-volt battery installed in the sensor will last up to 3 years.

The collector sends the wireless data transmission over the Verizon network so you can access information online from any internet connection, including your smart phone or tablet.

When changing out an empty cylinder, there will be no need to disassemble the sensor.

## Next Step:

Contact **Scott Humphrey** at **513-478-9104** or **scott@VMG.us.com** to register your username and password, and to watch an online demo of the dashboard, which will describe all the features and functions.

# Vendor Managed Gas



## Reference Sheet

---

### Website:

**wb.helixapps.com**

username: (your email address)

password: vmg123

### Tech Help:

**Mikey Ahrens**

mikey@VMG.us.com

(513) 346-0918

**Scott Humphrey**

scott@VMG.us.com

(513) 478-9104

### Our Website:

**www.VMG.us.com**